

ROTARY DRILLING

Testing and Completing



Third Edition, Rev.

UNIT II • LESSON 5



ROTARY DRILLING SERIES

Unit I: The Rig and Its Maintenance

- Lesson 1: The Rotary Rig and Its Components
- Lesson 2: The Bit
- Lesson 3: Drill String and Drill Collars
- Lesson 4: Rotary, Kelly, Swivel, Tongs, and Top Drive
- Lesson 5: The Blocks and Drilling Line
- Lesson 6: The Drawworks and the Compound
- Lesson 7: Drilling Fluids, Mud Pumps, and Conditioning Equipment
- Lesson 8: Diesel Engines and Electric Power
- Lesson 9: The Auxiliaries
- Lesson 10: Safety on the Rig

Unit II: Normal Drilling Operations

- Lesson 1: Making Hole
- Lesson 2: Drilling Fluids
- Lesson 3: Drilling a Straight Hole
- Lesson 4: Casing and Cementing
- Lesson 5: Testing and Completing

Unit III: Nonroutine Operations

- Lesson 1: Controlled Directional Drilling
- Lesson 2: Open-Hole Fishing
- Lesson 3: Blowout Prevention

Unit IV: Man Management and Rig Management

Unit V: Offshore Technology

- Lesson 1: Wind, Waves, and Weather
- Lesson 2: Spread Mooring Systems
- Lesson 3: Buoyancy, Stability, and Trim
- Lesson 4: Jacking Systems and Rig Moving Procedures
- Lesson 5: Diving and Equipment
- Lesson 6: Vessel Inspection and Maintenance
- Lesson 7: Helicopter Safety
- Lesson 8: Orientation for Offshore Crane Operations
- Lesson 9: Life Offshore
- Lesson 10: Marine Riser Systems and Subsea Blowout Preventers

Contents

Figures	v
Tables	vi
Foreword	vii
Preface	ix
Acknowledgments	xi
Units of Measurement	xii
Introduction	1
Reservoir Characteristics	2
Reservoir Rock Types	2
Porosity	4
Permeability	5
Thickness	7
Saturation	7
Pressure and Temperature	8
Corrosive Fluids	8
To Summarize	9
Formation Evaluation	11
Seismic Surveys	11
Records from Nearby Wells	12
Driller's Logs	12
Mud Logs	13
Core Samples	14
Wireline Well Logs	16
Logging While Drilling	25
Formation Evaluation Data	25
To Summarize	25
Formation Testing	27
Wireline Formation Test	28
Drill-Stem Test	30
Surface Well Tests	36
Usefulness of Test Data	41
To Summarize	42
Completion Design	43
Completion Methods	43
Flow Paths	46
Completion Systems	48
Cost versus Potential	53
To Summarize	54
Completion Tools	55
Tubing	55
Production Packers	57
Seating or Landing Nipples	62



Flow-Control Equipment	62
Erosion-Control Equipment	65
Wellheads	67
Completion Procedures	71
To Summarize	71
Perforating	73
Jet Perforating	74
Stimulation	78
Running the Completion	80
To Summarize	83
Glossary	85
Review Questions	107
Index	115
Answer Key	123

Units of Measurement



Throughout the world, two systems of measurement dominate: the English system and the metric system. Today, the United States is one of only a few countries that employ the English system.

The English system uses the pound as the unit of weight, the foot as the unit of length, and the gallon as the unit of capacity. In the English system, for example, 1 foot equals 12 inches, 1 yard equals 36 inches, and 1 mile equals 5,280 feet or 1,760 yards.

The metric system uses the gram as the unit of weight, the metre as the unit of length, and the litre as the unit of capacity. In the metric system, 1 metre equals 10 decimetres, 100 centimetres, or 1,000 millimetres. A kilometre equals 1,000 metres. The metric system, unlike the English system, uses a base of 10; thus, it is easy to convert from one unit to another. To convert from one unit to another in the English system, you must memorize or look up the values.

In the late 1970s, the Eleventh General Conference on Weights and Measures described and adopted the Systeme International (SI) d'Unités. Conference participants based the SI system on the metric system and designed it as an international standard of measurement.

The Rotary Drilling Series gives both English and SI units. And because the SI system employs the British spelling of many of the terms, the book follows those spelling rules as well. The unit of length, for example, is metre, not meter. (Note, however, that the unit of weight is gram, not gramme.)

To aid U.S. readers in making and understanding the conversion system, we include the table on the next page.

English-Units-to-SI-Units Conversion Factors

Quantity or Property	English Units	Multiply English Units By	To Obtain These SI Units
Length, depth, or height	inches (in.)	25.4	millimetres (mm)
		2.54	centimetres (cm)
	feet (ft)	0.3048	metres (m)
	yards (yd)	0.9144	metres (m)
	miles (mi)	1609.344	metres (m)
		1.61	kilometres (km)
Hole and pipe diameters, bit size	inches (in.)	25.4	millimetres (mm)
Drilling rate	feet per hour (ft/h)	0.3048	metres per hour (m/h)
Weight on bit	pounds (lb)	0.445	decanewtons (dN)
Nozzle size	32nds of an inch	0.8	millimetres (mm)
Volume	barrels (bbl)	0.159	cubic metres (m ³)
		159	litres (L)
	gallons per stroke (gal/stroke)	0.00379	cubic metres per stroke (m ³ /stroke)
	ounces (oz)	29.57	millilitres (mL)
	cubic inches (in. ³)	16.387	cubic centimetres (cm ³)
	cubic feet (ft ³)	28.3169	litres (L)
		0.0283	cubic metres (m ³)
	quarts (qt)	0.9464	litres (L)
	gallons (gal)	3.7854	litres (L)
	gallons (gal)	0.00379	cubic metres (m ³)
	pounds per barrel (lb/bbl)	2.895	kilograms per cubic metre (kg/m ³)
	barrels per ton (bbl/tn)	0.175	cubic metres per tonne (m ³ /t)
Pump output and flow rate	gallons per minute (gpm)	0.00379	cubic metres per minute (m ³ /min)
	gallons per hour (gph)	0.00379	cubic metres per hour (m ³ /h)
	barrels per stroke (bbl/stroke)	0.159	cubic metres per stroke (m ³ /stroke)
	barrels per minute (bbl/min)	0.159	cubic metres per minute (m ³ /min)
Pressure	pounds per square inch (psi)	6.895	kilopascals (kPa)
		0.006895	megapascals (MPa)
Temperature	degrees Fahrenheit (°F)	$\frac{^{\circ}\text{F} - 32}{1.8}$	degrees Celsius (°C)
Mass (weight)	ounces (oz)	28.35	grams (g)
	pounds (lb)	453.59	grams (g)
		0.4536	kilograms (kg)
	tons (tn)	0.9072	tonnes (t)
	pounds per foot (lb/ft)	1.488	kilograms per metre (kg/m)
Mud weight	pounds per gallon (ppg)	119.82	kilograms per cubic metre (kg/m ³)
	pounds per cubic foot (lb/ft ³)	16.0	kilograms per cubic metre (kg/m ³)
Pressure gradient	pounds per square inch per foot (psi/ft)	22.621	kilopascals per metre (kPa/m)
Funnel viscosity	seconds per quart (s/qt)	1.057	seconds per litre (s/L)
Yield point	pounds per 100 square feet (lb/100 ft ²)	0.48	pascals (Pa)
Gel strength	pounds per 100 square feet (lb/100 ft ²)	0.48	pascals (Pa)
Filter cake thickness	32nds of an inch	0.8	millimetres (mm)
Power	horsepower (hp)	0.75	kilowatts (kW)
Area	square inches (in. ²)	6.45	square centimetres (cm ²)
	square feet (ft ²)	0.0929	square metres (m ²)
	square yards (yd ²)	0.8361	square metres (m ²)
	square miles (mi ²)	2.59	square kilometres (km ²)
	acre (ac)	0.40	hectare (ha)
Drilling line wear	ton-miles (tn•mi)	14.317	megajoules (MJ)
		1.459	tonne-kilometres (t•km)
Torque	foot-pounds (ft•lb)	1.3558	newton metres (N•m)

Petroleum Extension-The University of Texas at Austin



Introduction



In this chapter:

- Factors affecting fluid production
 - Reservoir rock formations
 - Porosity and permeability
 - Reservoir characteristics
-

Well completion methods vary a great deal because not only are no two wells exactly alike, but also no two producing companies handle a well the same way. It is impossible to talk about the typical well completion because it does not exist. Personal preferences and experience dictate the choices made in selecting individual steps taken during completion. A frequently heard comment is “there are 35 or 40 ways to complete a particular well and five of them are bad, so just avoid the bad ones.” Yet, the general completion process—the gathering, checking, and analyzing of data and the choosing, designing, and running of the completion—is the same for every well. Completion planning begins before drilling and continues through completion, stimulation, well servicing, and recompletion. The plan must take much information into account to reach the overall goal of every completion: that is, to produce the most oil and gas at the least possible cost. A well-planned completion accomplishes this goal in two ways. First, it recovers the maximum amount of petroleum (economically speaking) by producing reservoir fluids efficiently. Second, it saves possible later costs of equipment, workover, and recompletion through foresight in planning. No matter who plans a completion, reservoir conditions primarily, along with efficiency and foresight, decide the well’s success or failure.

To improve recovery of petroleum and reduce costs, a well completion must be planned carefully using data from testing.

Formation Evaluation



In this chapter:

- Evaluating subsurface formations
- Seismic surveys and well records
- Types of logs and measurements
- Identifying producing zones

In the early days of drilling when cable tool rigs dominated, the notion of sampling well bailings to find out what the bit was penetrating not only seemed unimportant but also a waste of time. If a well was going to produce, it would produce—sampling well bailings would not change that.

Today, it is still true that formation evaluation cannot change a well's production potential, but completion techniques suggested by formation data can. Formation evaluation is performed routinely and in more ways than early oil entrepreneurs could have dreamed. Methods for evaluation of subsurface formations now include the sophisticated use of seismic surveys, records from nearby wells, the driller's log, mud logs, core samples, and a multitude of wireline well logs.

Data used to evaluate subsurface formations:

- Seismic surveys
- Records from nearby wells
- Core samples
- Logs

Seismic surveys help in deciding where to drill because they give clues to where pay zones may exist (fig. 2). From a seismic record, the location, depth, and size of potential reservoirs can be predicted. Later, if a formation is found to hold petroleum, its volume can be estimated.

Seismic Surveys

Formation Testing



In this chapter:

- Types of formation tests
 - Wireline testing
 - Drill-stem tests and tools
 - Drill-stem assemblies and procedures
 - Surface well testing
 - Usefulness of various tests
-

Formation testing may be done before or after running casing, cementing, and perforating. (The few wells that are completed open hole, of course, are tested only open hole.) Cased-hole completions are tested through perforations. Open hole testing followed up by cased-hole testing is also standard in some areas.

The formation test is the final proof of a well's initial capability to produce oil and gas in paying quantities. Cores and logs tell which formations are likely to produce and where to perforate them, but predictions are not the best data on which to base an expensive completion. However, formation tests in general are most useful in reservoirs with medium to high permeability (greater than 15 or 20 millidarcys). In developed areas where log analysis has proved to be successful in identifying potential completion formations, most operators forego the costs of formation testing.

Wireline formation testers and drill-stem test (DST) tools can be used during or after the conclusion of drilling. Both types of formation tests may be used on a well when considering it for completion.

Formation testing helps determine the production capability of a well and whether the well should be completed.

Completion Design



In this chapter:

- Common aspects of completion design
 - Well completion methods
 - Single and multiple flow paths
 - Completion systems for efficient production
 - Economic factors
-

No two wells are alike. Every good completion design takes into account the uniqueness of a well. It would be difficult to look at every possible completion design, but three items are part of every design process:

- Completion method most suitable for the well
- Completion system chosen to bring the fluids to the wellhead
- Completion cost versus production potential

The completion method chosen greatly affects the communication from the reservoir to the wellbore.

Basically, there are two methods:

- Open-hole completion
- Perforated completion

In conventional perforated completions, reservoir fluids communicate to the wellbore through perforations (holes) made in the casing and cement. Perforating must be delayed until the cement has properly set and the bond log has been run. In open-hole completions, casing is set and cemented at or near the top of the production interval, and the reservoir is drilled with a bit that is smaller than the inside diameter of the casing. Coal-bed methane wells and horizontal wells are often completed in open hole.

Completion Methods

Completion Tools



In this chapter:

- Basic classes of completion tools
- The importance of tubing
- Tubing strength ratings
- Common types of flow-control equipment
- The impact of production methods

Today's oilfield technology offers numerous possibilities for completing a well. While every well is unique and for every well there is a unique completion, all completion designs include certain options. Although a range of modern completion equipment that seems almost limitless provides these options, all completion tools fall under a few basic classes. Each class fills a specific need in completion design. The numerous combinations of these basic tools allow a completion to be tailored to suit the well. These basic tools include tubing, packers, seating nipples, flow-control equipment, erosion-control equipment, wellheads, and when necessary, artificial lift.

Tubing

A tubing string is an important completion option and is usually the first consideration in completion design (fig. 26). When used with various equipment options, tubing is the heart of a completion system.

Tubing Strength Ratings

Every type of tubing is assigned American Petroleum Institute (API) ratings for tensile, collapse, and burst strength. *Tensile strength* is the maximum pull that the tubing can bear from its own weight, plus any added pull required to unseat packers or anchors. If the pull is too great, the tubing will stretch until it parts. *Collapse strength* is the maximum



COURTESY OF ENTRAC PETROLEUM: E-LEARNING TRAINING SPECIALISTS

Figure 26. Tubing ready to be run into a well

Perforating



In this chapter:

- Perforating methods
- The three stages of stimulation
- Running the completion
- Cleaning up the well

The advent of gun perforating in the 1930s made it easy to shoot round, uniform holes in cemented casing. Until then, passages for formation fluids had to be made in cased, cemented wells with clumsy, unreliable mechanical perforators that slowly gouged each hole needed, sometimes badly damaging the casing in the process. The disadvantages of early perforating techniques made the open hole a common completion choice at the time.

Gun perforating radically changed completion technology. It allowed the entire well to be cased through and specific zones to be produced by means of accurately placed perforations. Acidizing and fracturing techniques almost always work better in wells where the petroleum reservoir is isolated from other formations. Also, multiple zones separated from one another in the same wellbore produce more efficiently. Zone isolation has become a legal requirement in many areas with commingling allowed only with proper request and permission. Effective perforating techniques have helped to make all these things possible.

Originally, gun perforating used actual bullets fired at the casing to penetrate cement and formation rock. It was cheap, effective, and fast. But bullet perforating has pressure and temperature limitations. During World War II, bazooka technology was used to develop jet perforating, which has since become the method of choice for a very high percentage of cased-through completions.

Benefits of gun perforating:

- Less damage to casing (than with the previous method)
- More accurately placed perforations
- Selective perforation of the casing in certain zones

Index



Throughout this index, *f* represents a figure on that page.

acid for well stimulation, 78, 79

acid wash, 77

acidizing, 73

acoustic logs, 23

acre feet, 5

American Petroleum Institute (API), 55

annular pressure, 56, 58

annular production, 40

annular space, 44

annulus

in the DST assembly, 31, 32, 33

flow control and, 62

monitoring, 68, 81

in a multiple-zone conventional system, 49, 49*f*, 50

sliding sleeves and, 62

API gravity, 40–41

API standard gamma ray units, 21

artificial lift, 44, 70, 71

in an open-hole completion, 44

back surging, 77

bare-foot completion, 44

barrel cores, 14, 14*f*, 26

barrels, oil, 53, 78

bazooka technology, 73

beam pumping, 70, 70*f*

biscuit cutter, 14

bit cones, 80

bit cuttings, 13

bits, 14, 15*f*, 17, 43

blast joints, 65, 66, 72

blow and flow periods, 35

blowout preventers, 82

blowouts, 14, 32, 42, 64

bond log, 43

bottomhole pressure, 36, 39, 40

bottomhole pressure gauge, 28, 38

box and pin, 56

braided-line DST, 32

breathing (tubing), 56, 72

brine solution, 8, 38, 76, 82

bubble bucket, 33

bulk density, 21

bulk fluid samples, 38

bullet method. *See* gun perforating

burner (offshore), 37*f*, 38

burst strength, 56, 71

butane, 8

calcite, 4

calcium, 4, 9, 21

calcium carbonate, 3

calcium magnesium carbonate, 3

caliper logs, 17

carbon, 21

carbon dioxide, 8, 35, 40, 46, 57, 79

carbonate reservoirs, 44, 54

carbonate rock, 2*f*, 3, 9

cased-hole completions, 27

casing

for jet perforating, 74*f*

perforated completions and, 44, 45*f*

protecting from erosion, 66*f*

single-string dual completion and, 50

casing hanger, 67*f*, 68, 72, 82

casing pressure, 40

casing scraper, 80

casing string, 45, 52, 56, 57, 68

casingheads, 67*f*, 68, 72, 82

casing-tubing annulus

in a conventional system, 48, 48*f*, 49

monitoring, 33

packer fluid in, 82, 83

pressure in, 40

producing gas through, 50, 58

single flow path, 46

sliding sleeves, 62

caving formations, wellbore and, 17

TESTING AND COMPLETING

- caving sidewalls, 36, 44
- cement bond log, 80
- cement wiper plug, 80
- cementing
 - casing strings, 5, 52
 - completion methods and, 36, 43, 54, 71
 - in conventional systems, 48, 54
 - designing program of, 17
 - erosion and, 57
 - mineral, 4
 - perforating, 44, 45*f*, 73
- charging case, 74*f*
- check plugs, 63
- check valves, 63, 63*f*, 72
- chemical concentrations, 18, 19
- chlorine, 21
- choke manifold, 36, 38–39
- Christmas tree, 36, 67*f*, 69, 69*f*, 72
- circulation, 46, 47, 62, 80
- clastic rock, 2*f*, 3, 9
- clay
 - acoustic logs and, 23
 - permeability and, 21, 35
 - porosity of, 4, 5, 6
 - stabilizing chemicals, 79
 - swelling, 76
- cleats, 3, 9
- coal, methane adsorbed onto, 3, 9
- coal-bed methane
 - completion design, 43, 44, 54
 - development of, 2
 - differing completion procedures for, 71
 - overview of, 3–4, 9
- collapse strength, 55–56, 71
- compacting from pressure, 4
- completion design
 - cost versus potential, 53, 54
 - flow paths, 46–47
 - methods of, 43–45
 - overview of, 43
 - specialized systems, 52–53
 - systems for, 48–53
 - variations in, 1
- completion systems
 - conventional, 48–50, 48*f*, 51*f*, 54
 - specialized, 52–53
- completion tools. *See also* equipment
 - corrosive fluids and, 8, 10, 35
 - erosion-control equipment, 65–66
 - flow-control equipment, 62–64
 - gun perforating, 73
 - inspecting, 81
 - overview of, 71
 - permanent packers, 61, 61*f*
 - production packers, 57–60, 58*f*
 - retrievable packers, 60
 - running and setting, 81
 - seating/landing nipples, 62
 - tubing, 55–56
 - wellheads, 67–71, 67*f*
- composition, 41
- compression packer, 60, 60*f*, 81
- conditioning. *See* wellbore conditioning
- conductor line, 16, 17*f*, 28, 38
- connections
 - porosity and, 5–6
 - testing, 38
 - tubing, 56, 60, 71, 81
- contact, 25, 35
- conventional systems for completion, 48–49, 54
- coral reefs, 3, 4
- core analysis, 16
- core samples
 - analysis of, 16
 - to analyze formation competence, 45
 - barrel, 14
 - limitations of, 27
 - overview of, 14
 - sidewall, 15, 15*f*
 - typical size of, 14
- coring gun, 15, 15*f*
- corrodents, 8, 10, 35, 57
- corrosive fluids. *See also* fluids
 - completion tools and, 8, 10, 35
 - inhibitors, 79, 82
 - overview of, 8, 10
 - perforated completions and, 44
 - as a reservoir characteristic, 2
 - in well stimulation, 79
- costs of well completion, 52, 53, 54
- coupling, 56
- crude oil, 40–41, 71
- cubic metres, measuring rock volume with, 5
- cushion, DST test and, 32, 33
- cuttings, 13, 32
- cyclonite, 75
- darcy, 5, 9
- d'Arcy, Henri, 5
- data, usefulness of, 41
- debris
 - cleaning out, 38, 77
 - flushing, 76, 80

- forming hydrocarbons, 3, 9
- decentralizer in a resonance log, 23, 23f
- deep wells, 61
- density log, 21
- detonating cord, 74f, 75
- differential gas pressure, 40
- differential pressure, 56
- dissolved gas, 58
- dolomite, 2f, 3, 22
- dolomitization, 4, 9
- drag blocks, 59, 59f
- drag springs, 59, 59f
- drill collars, 33
- driller's logs, 12, 26
- drilling fluids. *See* fluids
- drilling mud, 80, 83
- drilling rig, 82
- drill-stem test (DST)
 - assembly for, 31–32, 42
 - compared to surface well test, 36
 - interpretation, 34–35, 34f
 - overview of, 42
 - procedures for, 32–33, 42
 - tools for, 30–31
 - usefulness of, 41
- dry gas, 53, 54
- dual completion, 47
- efficiency
 - lift, 50
 - production packers and, 57, 58
 - pumping, 46
 - in well completion, 1, 53
- electric line conveyed perforating guns, 76
- electrical current, 16, 18, 19, 22f
- electric-line set packers, 60, 72
- elements, natural, 21
- emulsion formation, 76
- energized systems, 79
- equipment. *See also* completion tools
 - artificial lift, 44, 71
 - for barrel cores, 14
 - caliper, 17
 - corrosive fluids and, 8, 10, 35
 - costs of, 1, 53, 54
 - for a drill-stem test, 30–31, 30f, 32, 42
 - erosion control, 65–66
 - flow control, 62–64, 71, 72
 - for high pressure completions, 81
 - for magnetic resonance, 23
 - for a miniature completion, 52
 - for surface well tests, 36, 37f
 - wellheads, 67–71
 - wireline formation tester, 28–29, 28f
- erosion, 57, 65–66
- experience and judgement, 1, 31, 50
- explosive charges, 44, 60, 74–75
- fissures, 6
- flange, 68
- flanging up, 82
- flares, 37, 38
- flexure, 17
- flow coupling, 66, 66f, 72
- flow paths, 46–47, 54, 65
- flow period, 29, 33, 39, 42
- flow pressure, 38
- flow rates
 - after completion, 82
 - equipment for, 72
 - oil and water, 40
 - in an open-hole completion, 44
 - production packers and, 57
 - storage tank for low, 38
 - subsurface safety valves, 64
 - in the surface well test, 39
 - well testing and, 36
- flow-control equipment, 62–64
- flowing the well, 38
- flow-line manifold, 36, 37f, 38
- fluid migration, 44
- fluids. *See also* corrosive fluids; formation fluids; reservoir fluids
 - analyzing through a DST, 34, 35
 - bulk samples of, 38
 - chemical concentrations of, 18
 - for completion, 76, 83
 - identifying with a drill-stem test, 32
 - jet perforating and, 74
 - for packers, 82, 83
 - perforation, 38
 - production packers holding velocity of, 57
 - sampling during a DST, 33
- for well stimulation, 78–79
- formation competence, 45
 - formation evaluation
 - core samples, 14–16
 - damage in, estimating through a DST, 35
 - driller's logs, 12
 - to find the most promising pay zones, 25, 26
 - logging while drilling, 25
 - mud logs for, 13
 - records of nearby wells, 12, 25

TESTING AND COMPLETING

- seismic surveys, 11, 12*f*, 25
- suggesting completion techniques, 11, 25
- surface well tests, 36–41
- wireline well logs, 16–24
- formation fluids. *See also* fluids
 - chemical concentrations of, 18
 - corrodents in, 8, 10
 - DST and, 31, 32, 33
 - particles in causing erosion, 57
 - properties of, 7
 - salt content in, 18
 - sampling, 28
- formation sediments, 21
- formation testing
 - drill-stem test, 30–36
 - overview of, 27, 42
 - usefulness of, 41
 - wireline formation test, 28–29
- formation water resistivity, 18
- fossils, 16
- four-point test, 38
- fractures, 3, 9
- fracturing techniques, 73
- friction blocks/springs, 59
- gamma ray log, 18, 21
- gas, 13
- gas chromatography, 40
- gas composition, 40
- gas influx, 44
- gas lift, 70
- gas pressure, 58
- gas saturation, 7
- gas temperature, 40
- gas wells, 41, 46–47, 82
- gas-in-oil solubility, 41
- gas-lift mandrels, 70
- gas-oil contact, 35
- gas-separation chamber, 46
- gathering systems, 82
- gauge ring, 80
- Geiger counter, 21
- geological marker beds, 12
- geological pressures, 4, 9
- graphing, 35
- gravel pack, 45, 66
- gun perforating, 73, 76
- gypsum, 78
- heading, 58
- heater, 36, 37, 37*f*
- heating value, 41
- HMX, 75
- hold-down buttons, 59, 59*f*
- horizontal wells
 - completion design, 43
 - differing completion procedures for, 71
 - open-hole completion, 44, 54
- hydrate formation, 40
- hydrates, 37
- hydraulic fracturing, 78
- hydraulic jet perforating, 78
- hydraulic-lift systems, 70
- hydraulic-set packers, 60, 72
- hydrocarbons
 - calculating density of through density logs, 21
 - gamma ray logs and, 21
 - knowing content of, 8
 - light, 8
 - origins of, 3
 - presence of and resistivity logs, 19
- hydrogen, 21
- hydrogen sulfide, 8, 35, 40, 46, 57
- hydrostatic pressure, 29
- igneous rocks, 2
- impermeable formations, 3, 18, 21
- induction log/survey, 19
- infill wells, 14
- inflatable straddle tools, 42
- inorganic theory of oil and gas, 3
- interface. *See* contact
- intermediate casing, 67*f*
- invaded zone, 18, 19
- jet perforating, 73, 74–75, 74*f*, 83
- junk, 32
- junk basket, 80
- kill line, 37*f*
- killing a well, 46
- landing nipples. *See* seating/landing nipples
- landing the wellhead, 82
- lateral bit movement, wellbore and, 17
- lateral focus log, 19
- leaching, 4, 9, 21
- limestone, 2*f*, 3, 5, 22
- loading, 46–47, 57, 72
- log off, 57
- logging while drilling, 25, 26

- long-reach horizontal drilling, 25
- low-pressure wells, 53, 54, 70
- low-volume well, miniature completion for, 52

- magnesium, 4, 9
- magnetic field, 16, 19
- magnetic resonance logs, 23, 23*f*
- manifolds, 36, 37*f*, 38–39
- marker bed, 12
- market value and price, 40–41
- mass spectrometer, 40
- master valve, 67*f*, 69
- matrix, 3, 9, 29
- maximum run-in speed, 81
- mechanical-set packers, 60, 72
- metamorphic rocks, 2
- methane, 2, 3–4, 9, 40
- microresistivity log, 19
- millidarcy (md), 5, 9
- millivolts, 18
- mineral cement, 4
- minerals, 18, 21, 35
- miners, 3–4
- miniaturized completions, 52, 52*f*, 54
- mud cake, 17, 19, 32, 80
- mud filtrate, 16, 18, 38
- mud logs, 13, 13*f*, 26
- multiple completion, 47, 52, 52*f*, 69
- multiple flow paths, 47, 54
- multiple-zone conventional systems, 49

- natural gas, 2, 7, 40
- negative-pressure perforating, 77
- neutral-set packers, 60, 81
- neutron log, 21
- nitrogen, 32, 40, 79
- nuclear logs, 22, 22*f*

- offshore tests, 37
- offshore wells, 64
- ohmmeters, 19
- oil and gas fields/shows, 12, 29
- oil and gas separator, 37
- oil flow rate, 40
- oil meter, 40
- oil residue, 13
- oil-based well stimulation, 79
- oil-shale yield, 21
- oil-water contact, 35

- older wells, 8
- open-hole completion, 43, 44, 44*f*, 54
- open-hole logs, 14, 41. *See also* wireline well logs
- open-hole wells, 27, 36
- organic theory of oil and gas, 3
- oriented perforating, 53
- orifice plate, 40
- oxygen, 21

- packer, 50, 51*f*
- packer seal, setting, 33
- packing elements, for production packers, 58, 58*f*, 59*f*, 81
- parallel-string completion, 50, 51*f*
- particles, 4
- pay sands, 12
- pay zones, 11, 12*f*, 25, 26, 29, 62
- perforated completion, 43, 44, 45*f*, 54
- perforating
 - cleaning up after, 77
 - early techniques in, 73
 - electric line conveyed perforating guns, 76
 - final steps of, 80–83
 - hydraulic jet, 78
 - jet, 74–75, 74*f*, 83
 - procedures for, 76–77
 - stimulation techniques, 78–79
 - time of, 81, 83
 - tubing-conveyed guns, 77
- perforating unbalanced, 77
- perforation fluid, 38
- perforations
 - cementing and, 43
 - debris from, 38
 - in a perforated completion, 45*f*
 - testing through, 27
- permanent packers, 61, 61*f*, 72, 81
- permeability
 - estimating through a DST, 34, 35
 - estimating through coring samples, 16
 - estimating with a wireline formation test, 29
 - formation testing and, 27
 - overview of, 5–6, 9
 - of a reservoir, 2
 - resistivity logs and, 20*f*
 - variations in, 6*t*
- petroleum reservoir, 9, 73
- photoelectric effect, 22
- photoelectric effect (Pe), 22
- pinch out, 35
- pipe strings, 56

TESTING AND COMPLETING

- pit, 37
- plunger-lift device, 46–47
- polished bore receptacle (PBR), 61
- pore connections, 5, 6
- pores, 5, 7
- porosity
 - calculating through density logs, 21
 - calculating with a resistivity log, 19, 20*f*
 - estimating through coring samples, 16
 - estimating through magnetic resonance logs, 23
 - need for along with permeability, 5
 - overview of, 4, 9
 - as a reservoir characteristic, 2
 - resistivity logs and, 19
 - variations in, 6*t*
- potential of a well, 53, 54
- pressure
 - casing and tubing heads rated by, 68
 - cleaning a well and, 77
 - estimating through a DST, 34, 35
 - in the formation, 42
 - heading and, 58
 - hold-down buttons and, 59
 - jet perforating and, 74
 - measuring with a wireline formation test, 28
 - obtaining data on with a drill-stem test, 32
 - in an open-hole completion, 44
 - production packers and, 57
 - of a reservoir, 8
 - as a reservoir characteristic, 2, 10
 - running and setting perforating tools and, 81
 - thief zones, 58
 - tubing and, 56
 - wireline formation tests and, 29
- pressure behavior plots, 34, 34*f*, 35, 40
- pressure gauge, 67*f*
- pressure recorders, 31, 36, 42
- pressure-depletion rates, 35
- primary porosity, 4
- producing zones, 25, 44, 46, 47, 49–50, 58
- production casing, 46, 52, 67*f*
- production efficiency, 58
- production maintenance, 53, 54
- production packers
 - maximum run-in speed, 81
 - overview of, 57–60, 58*f*, 72
 - running and setting perforating tools and, 83
 - testing, 81, 83
- progressing cavity pumping, 70, 71
- propane, 8
- pump rates, 56
- pumping methods, 46
- quartz, 6
- radioactive elements, 16, 21, 22
- radioactivity logs, 21–22, 22*f*
- radius of investigation, 35
- RDX, 75
- recompletion, 53, 54
- recordings, 35
- records. *See also* wireline well logs
 - driller's logs, 12
 - initial shut-in pressure, 38
 - mud logs, 13
 - of nearby wells, 12, 16, 25
- refinery process, 41
- regulations and laws, 41, 47, 58, 73
- relative permeability, 7
- relative permeability to reservoir fluids, 2
- reserves, 40–41
- reservoir, 2, 4, 9
- reservoir fluids, 2, 8, 43, 47. *See also* fluids
- reservoir pressure. *See* pressure
- reservoir rock types, 2–4, 2*f*, 9
- resistivity logs, 19, 20*f*, 22*f*
- retrievable guns, 76
- retrievable packers, 60, 72
- reverse-balloon, 56
- reverse-pressure perforating, 77
- rivers and streams, leaching inorganic compounds, 3
- rock type, 21
- routine well service, 53, 54
- run-in speed, maximum, 81
- safety, 53, 79, 80. *See also* subsurface safety valves
- salt content, 18, 21, 35, 46
- salt water, 7, 57
- sand
 - abrasion from, 66
 - erosion and, 46, 57, 65
 - identifying with a photoelectric curve, 22
 - open-hole completion and, 44, 45
 - permeability in, 5
 - porosity in, 4
 - sizes in, 79
 - wells producing high amounts of, 71
- sand proponents, 78, 79
- sanding off, 57
- sandlines, 45
- sandstone, 2*f*, 3, 4, 5
- saturation
 - analyzing through a DST, 35
 - estimating through magnetic resonance logs, 23

- gamma ray logs and, 21
- overview of, 7
- as a reservoir characteristic, 2, 10
- resistivity logs and, 19
- screen liners, 45, 57, 66
- sea life/water, 3, 7, 9
- seal-bore assemblies, 61
- seating/landing nipples, 62, 62*f*, 63, 66*f*, 72
- secondary porosity, 4, 9
- secondary recovery operations, 14
- sediment, 45, 57, 65
- sediment and water (S&W), 41
- sedimentary rocks, 2, 2*f*, 3, 9
- seismic surveys, 11, 12*f*, 25
- semipermanent packers, 61, 72
- separator, 36, 37*f*, 38
- shale, 2*f*, 3, 6, 22, 23
- shallow wells, 53, 54, 71
- shaped perforating charge case, 75, 75*f*, 76
- shifting tool, 62
- shut-in periods, 33, 35, 42, 46, 56
- shut-in pressure, 29, 38, 39
- sidewall cores, 15, 15*f*, 16, 26
- silicon, 21
- single flow paths, 46, 54
- single-packer DST tool, 30–31, 30*f*, 42
- single-string dual completion, 49–50, 49*f*, 50*f*
- single-zone completion with tubing and packer, 48, 48*f*
- sliding sleeves, 62, 63*f*, 72
- slips, for production packers, 58–59, 58*f*, 59*f*, 60, 81
- smokeless burners, 37
- sniffer, 13
- solution gas, 7
- sonde
 - gamma ray, 21
 - for resistivity logs, 49
 - typical logging run, 24, 24*f*
 - for a wireline formation test, 28
 - wireline well logs, 16, 17*f*
- sonic log, 23
- sour wells, 8
- specific gravity, 40, 41
- spontaneous potential logs (SP), 18, 18*f*, 21, 22*f*
- standing valves, 63
- static gas pressure, 40
- steam floods, 45
- stimulation techniques, 5, 44, 56, 78–79, 83
- stock tank measurement, 41
- storage tank, 38
- storm chokes, 64
- straddle-packer DST tool, 30–31, 30*f*, 42
- stripper rubber, 80
- subsurface safety valves, 64, 64*f*, 72. *See also* safety
- sucker-rod pumping, 56, 70
- surface casing, 67*f*
- surface controller, 47
- surface safety valves, 36
- surface test tree, 36, 37*f*, 40
- surface well tests
 - compared to drill-stem tests, 36
 - equipment for, 36–38
 - interpretation of results, 39–41, 39*f*
 - overview of, 42
 - procedures for, 38–39
 - usefulness of, 41
- swabbing, 46, 57, 72, 77
- sweet wells, 8
- Système International (SI) d'Unités, 5
- tank, 36, 37*f*, 38
- tank battery, 82
- temperature, 2, 8, 10, 32, 40
- tensile strength, 55, 71
- tension packers, 60, 60*f*, 81
- thickness, net, 7, 10
- thief zones, 58
- tools. *See* equipment
- tortuosity, 5, 6
- tubing
 - as a completion tool, 71
 - packers diverting pressure to, 57
 - in a parallel-string completion, 50, 51*f*
 - in production packers, 60
 - protecting from erosion, 65, 66*f*
 - for a single path, 46
 - strength rating of, 55–56
 - in the wellhead component, 67*f*
- tubing anchor, 56
- tubing connection, 56, 71
- tubing hanger, 67*f*, 68, 72
- tubing head, 67*f*, 68, 72
- tubing head swivel, 36, 37*f*
- tubing movement, 56, 72
- tubing pressure, 40
- tubing seal assemblies, 61
- tubing strength, 56, 71
- tubing string, 46, 62, 65
- tubing test string, 36
- tubing-conveyed perforating guns, 77
- tubingless completion, 53, 54

TESTING AND COMPLETING

tubing-mounted, 64
tubular, 67

unit rock volume, 5

valves

- check, 63, 63*f*, 72
- master, 64, 67*f*
- safety, 64, 64*f*, 72
- standing, 63

viscosity, 35

volume of petroleum, estimating, 11

vugs, 4, 6

wastewater disposal system, 37

water

- in a completion fluid, 76
- flow rate, 40
- methane dissolved into, 3, 9
- perforated completions and, 44
- resistivity logs and, 19

water based stimulation fluid, 78–79

water fracs, 78, 83

water reservoirs, 44

water saturation, 7

water-base acid, 78, 79, 83

water-base gel, 78–79, 83

well bailings, sampling, 11

well completion methods. *See* completion design

well logs, 24, 27

well productivity, 34, 35

well service, 69

wellbore

- cleaning out, 45
- distance from that data holds true, 35
- measuring diameter of with a caliper, 17
- perforated completions and, 44

- small, 36

wellbore annulus. *See* casing-tubing annulus

wellbore conditioning, 32, 42, 80

wellhead pressure, 40

wellheads, 67–71, 67*f*, 72

wells, 16

- cleaning up, 82

- dying off, 46, 57, 72

- flanging up, 82

- putting into production, 82

- records from nearby, 12, 16, 25

- routine service of, 53, 54

- specific gravity, 41

well-test reports, 39, 39*f*, 41

whole cores, 14

wing, 67*f*, 69

wiper plug, displacing, 80

wireline. *See* conductor line

wireline formation test, 28–29, 28*f*, 42

wireline logs, 14

wireline recorders, 40

wireline well logs. *See also* open-hole logs; records

- acoustic logs, 23

- caliper logs, 17

- gamma ray log, 21

- magnetic resonance logs, 23, 23*f*

- overview of, 16–17, 17*f*, 26

- radioactivity logs, 21–22

- resistivity logs, 19, 20*f*

- spontaneous potential logs (SP), 18, 18*f*

- usefulness of, 41

wireline-retrievable tool, 64, 66*f*

workover, 53, 54, 69

Y-sub, 50, 50*f*

zone isolation, 58, 62, 73

To obtain additional training materials, contact:

PETEX
THE UNIVERSITY OF TEXAS AT AUSTIN
PETROLEUM EXTENSION SERVICE

J.J. Pickle Research Campus
10100 Burnet Road, Bldg. 2
Austin, TX 78758

Telephone: 512-471-5940

or 800-687-4132

FAX: 512-471-9410

or 800-687-7839

E-mail: petex@www.utexas.edu

or visit our Web site: www.utexas.edu/ce/petex



To obtain information about training courses, contact:

PETEX
LEARNING AND ASSESSMENT CENTER
THE UNIVERSITY OF TEXAS

4702 N. Sam Houston Parkway West, Suite 800
Houston, TX 77086

Telephone: 281-397-2440

or 800-687-7052

FAX: 281-397-2441

E-mail: plach@www.utexas.edu

or visit our Web site: www.utexas.edu/ce/petex

Petroleum Extension-The University of Texas at Austin

ISBN 0-88698-192-1



9 780886 981921

2.205301
0-88698-192-1
978-0-88698-192-1